

PIRATE CRUISER®

R/C Yacht



If you have questions about operating or installing your new Megatech product, or if you are missing parts... Please Call Megatech First!

DO NOT RETURN THIS PRODUCT TO THE STORE

Call our Customer Service Department at:

(201) 662-2800

10:00am - 5:00pm, EST Monday through Friday (except holidays)

Technical assistance is also available on-line at www.megatech.com
or by e-mail to info@megatech.com

Thank you for purchasing Megatech's Pirate Cruiser® R/C Yacht. With careful operation and proper care, your new boat will be keep racing for a long, long time.



Safety Warnings



This device complies with part 15 of FCC rules.

Operation subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received,

Including interference that may cause undesired operation.

Please read this entire manual carefully before you attempt to operate your Pirate Cruiser R/C Yacht.

Installing the Antenna

Slide the antenna into the hole on top of the radio transmitter. Next rotate the antenna clockwise until it stops. Be careful not to over-tighten.



Battery Requirements:

Four (4) C alkaline batteries and one (1) 9-volt alkaline battery.

Installing the Radio Transmitter Batteries

Remove the battery cover from the rear of your radio transmitter. Install a fresh 9-volt battery, paying careful attention to the polarity. Slide the battery cover back into place. **NOTE:** Since your boat is controlled by a radio link, it is very important to always use fresh alkaline batteries in the transmitter. We recommend Megatech's Golden Power series, designed for R/C products.

Installing the Pirate Cruiser R/C Yacht Batteries

Remove the battery compartment hatch cover and make sure the ON/OFF switch is set to OFF.




Install four (4) fresh C alkaline batteries into the compartment, paying attention to the polarity.

Replace the battery compartment hatch cover. Make sure it is securely sealed to keep water out of the hatch.

Operating Controls

- The left stick controls the left propeller (forward and reverse).
- The right stick controls the right propeller (forward and reverse).
- Push both sticks forward and the boat will go forward.
- Pull both sticks back and the boat will go in reverse.
- Push only the left stick forward and the boat will turn to the right.
- Push only the right stick forward and the boat will turn to the left.



Operating your new Pirate Cruiser R/C Yacht

1. Fully extend your transmitter antenna.
2. Switch on the boat.
3. Place the boat gently into the water.
4. Follow the operating controls mentioned above and have fun!

Safety Precautions

- When operating, always be aware of spinning propellers. Be careful not to let them come close to your person, others and/or loose clothing.
- Always remove the batteries from your boat when not in use.
- If you find your speed to be slowing down, replace your batteries immediately.
- Do not operate your boat more than 120' away from you. It could run out of range.
- Use your Pirate Cruiser R/C Yacht in shallow water, such as a pool or a pond with no waves and a minimum depth of 6" free of water grass.
- Always operate with adult supervision

Limited Warranty

Megatech® International guarantees this item to be free from defects for a period of 90 days from date of purchase. If any component of this product fails to function properly due to defects in materials or manufacturing process during this 90 day period, the manufacturer's obligations are limited and manufacturer can choose to either repair or replace the item. This warranty is void if the product in question has been altered or repaired by anyone other than Megatech® International or an authorized agent.

Under no circumstances will Megatech® International or any of its representatives be held liable for injury to persons or property damage resulting from assembly or use of the product. Megatech® is not liable if any outside radio frequencies interfere with the product's frequency causing loss of control. Megatech® International will not be held liable for any injury to persons or property damage resulting from an out-of-control model caused by use or misuse of the product. Megatech® International expressly excludes any and all express warranties not specifically stated here and all implied warranties of merchantability and fitness for a particular purpose. There are no warranties which extend beyond the description of the warranties contained herein.

Contact the Megatech® International Service Department before returning any item that is defective according to the limitations listed above. Please be sure to pack the returned item(s) carefully. The customer must return the product along with proof of purchase, a letter describing the problem and the customer's address and telephone number. At this point in time we will either repair the defective part or replace it and return it to the customer. Return shipping and handling in the 48 contiguous states is \$12.99. Shipping outside of the 48 states will be quoted by location.

This warranty does not cover any damage caused by use, misuse, alteration, accident, or neglect, nor does it cover normal wear and tear of the product. Product returned to us which falls under this category will be submitted to our service department for repair. We reserve the right to charge any service and parts fees incurred when repairing the item.

Megatech® International
8300 Tonnelle Avenue
North Bergen, NJ 07047
(201) 662-2800
www.megatech.com

